


MINOLTA

E INSTRUCTION MANUAL


MAXXUM[®]

7000i


DATA PANEL



VIEWFINDER



NAMES OF PARTS



*** Do not touch**

Page number in parentheses indicates where to locate information about the part.

Your new Maxxum 7000i camera is the world's first truly intelligent autofocus SLR camera. All of the camera's functions are integrated for unparalleled ease of operation and ultimate precision. You can take sharply focused, properly exposed pictures one after another and rely on your Maxxum 7000i to deliver outstanding results from one roll of film to the next.

The following are the Maxxum 7000i's most impressive features:

- Intelligent autofocusing with predictive focus control and multiple autofocus sensors that enable faster, more precise focusing than ever before possible.
- Intelligent automatic exposure using the world's first multi-pattern metering system coupled to the autofocus system.
- Advanced automatic multi-program selection that instantly selects the exposure program for any lens you use.
- Intelligent automatic flash control to ensure perfectly exposed pictures in daylight, low light, or no light at all.
- Automatic film transport that enables taking sharply focused pictures at up to 3 frames per second.
- World's largest selection of autofocus system accessories, including Creative Expansion Cards, Maxxum Flash units, and more than 31 Maxxum autofocus lenses.

You probably want to begin using your new camera right away. But before you start, please read through this instruction manual to learn how your Maxxum 7000i operates.

TABLE OF CONTENTS

BASICS

| | |
|--|---|
| ATTACHING THE LENS | 4 |
| ATTACHING THE NECKSTRAP | 6 |
| PUTTING THE CAMERA IN ITS CASE | 8 |

BATTERY INFORMATION

| | |
|-------------------------------|----|
| Loading the battery | 9 |
| Battery check | 10 |

FILM INFORMATION

| | |
|------------------------------|----|
| Loading film | 12 |
| Film speed setting | 15 |
| Film rewind | 17 |

TAKING PICTURES

| | |
|-------------------------------------|----|
| Holding the camera | 19 |
| Fully automatic operation | 20 |

MAKING THE MOST OF YOUR CAMERA

| | |
|---------------------------|----|
| MAIN SWITCH | 23 |
| Audible signals | 23 |

FOCUSING

| | |
|---------------------------------|----|
| Focus-area selection | 24 |
| Automatic focusing | 26 |
| How to use focus hold | 27 |
| Manual focusing | 30 |

FILM-ADVANCE MODES

| | |
|--------------------------------|----|
| Single-frame advance | 33 |
| Continuous advance | 33 |

EXPOSURE CONTROL

| | |
|---|----|
| Program Mode | 34 |
| Program reset button | 34 |
| Aperture-priority mode | 38 |
| Shutter-priority mode | 41 |
| Manual mode | 44 |
| Aperture and shutter-speed settings | 47 |
| Metering system | 48 |
| Spot measurements | 49 |
| Exposure adjustment | 51 |

FLASH INFORMATION 54

OTHER FUNCTIONS

| | |
|--------------------------|----|
| Self-timer | 56 |
| Long exposures | 58 |

ACCESSORIES 61

TROUBLESHOOTING GUIDE 68

TECHNICAL DETAILS 70

CARE AND STORAGE 75


IMPORTANT INFORMATION

The Minolta Maxxum 7000i camera is designed to offer innovative functions and performance through the combination of the camera body, Maxxum AF lenses, Minolta Maxxum Flash units, and other accessories distributed by Minolta. We thus caution users that the attachment or use of incompatible lenses, flashes, and accessories may result in unsatisfactory performance or damage to the Minolta Maxxum 7000i camera. To obtain optimum performance throughout the life of your Minolta Maxxum 7000i camera, we recommend that you use only lenses, flashes, and other accessories distributed by Minolta for the Maxxum 7000i camera.

BASICS


| | |
|--------------|----|
| Lens | 4 |
| Neckstrap | 6 |
| Camera Cases | 8 |
| Battery | 9 |
| Film | 12 |

ATTACHING THE LENS




To attach:

1. Remove body cap and rear lens cap as shown.



2. Align red bead on lens barrel with red dot on camera's lens mount. Insert lens bayonet into mount and turn lens clockwise until it locks in place with a click.



To remove:

1. While pressing lens release, turn lens counterclockwise as far as it will go, then lift lens out of mount.
2. Attach another lens or the body cap to prevent dust from entering the camera.

When the camera is set to A or M mode and the lens is removed, the aperture display in the data panel and viewfinder shows “- -”.


NOTE

- When attaching or removing lenses, never touch anything inside the camera, especially the lens contacts or mirror.
- To protect the lens contacts and the lens elements, attach the lens caps whenever the lens is not in use.


Care Of Glass Surfaces

- Never touch lens elements or the camera’s eyepiece with your fingers. If the lens becomes dirty, clean it gently with a lens brush. Only if necessary, moisten a sheet of lens tissue with one drop of lens-cleaning fluid. Then, starting at the center and using a circular motion, lightly wipe the surface of the lens.
- Never lift the mirror or touch its surface, as this may impair its alignment. Dust specks on the mirror’s surface will not affect exposure or picture quality. If the dust specks are annoying, the camera can be cleaned at an authorized Minolta service facility.

ATTACHING THE NECKSTRAP AND EYEPiece CAP






A neckstrap is supplied with your Maxxum 7000i. Attach it to the camera as shown above. An eyepiece cap is also supplied and can be slipped onto the neckstrap to keep it handy for use.



The eyepiece cap slides over the eyepiece frame to prevent stray light from entering the eyepiece and affecting exposure. It should be used whenever the eyepiece is not shielded by your head, as when using the self-timer or when operating the camera by remote control. To attach the eyepiece cap, first remove the Eyepiece Cup EC-7, then slip the cap over the frame.

An accessory shoe cap is supplied that slips into the accessory shoe to protect the contacts from dust and grime. When using a flash unit, slip the accessory shoe cap into the eyepiece cap.

PUTTING CAMERA IN ITS CASE






Various camera cases are available as optional accessories for the Maxxum 7000i.

To put camera in its case:

1. Attach lens cap.
2. If using a zoom lens, turn zoom ring until lens barrel is at its shortest position.
3. Follow the diagrams to put camera into case.

BATTERY INFORMATION



The Maxxum 7000i uses a 6-volt 2CR5 lithium battery. This battery supplies power for all camera operations, including film winding, autofocusing, and exposure control.

Loading The Battery

1. With main switch at LOCK position, use a coin or similar object to turn the battery-cover lock to OPEN position. Remove battery cover from camera.


2. Wipe battery terminals with a dry cloth to ensure proper contact. Insert the lithium battery according to the marks in the battery compartment.

3. Replace battery cover and turn the battery-cover lock to CLOSE position to secure it.


NOTE

- Read and follow all warnings and instructions supplied by the battery manufacturer.
- Keep battery away from young children.
- Do not attempt to disassemble, recharge, or short out the battery, or subject it to high temperatures or fire. The battery may explode and cause burns.


Checking The Battery Condition

Each time you slide the main switch from LOCK to ON or  position, the camera automatically checks the battery's condition:


Full-battery symbol appears for five seconds when power is sufficient.




Low-battery symbol appears for five seconds: Power is getting low – keep a fresh battery handy.



Low-battery symbol blinks: Camera can be operated, but the battery will need to be changed soon.



Blinking low-battery symbol appears alone or no indications appear: power is too low for normal operation — change battery immediately. (Note: in this case the shutter locks and the camera may also beep for one second as an additional low-battery signal.)



Cold-weather Operation




Lithium batteries provide excellent performance in cold weather. However, if you plan to shoot many rolls of film outdoors at 32°F (0°C) or below, we recommend that you carry the camera inside your coat to keep it warm when you are not taking pictures. You may also wish to carry a spare battery in a warm pocket, so that you can change the battery, if necessary. In this case, do not discard a cold battery since its capacity may be restored when it warms up.

Battery Performance


The 6-volt 2CR5 lithium battery should provide sufficient power for shooting up to 65 rolls of 24-exposure film, 50 rolls of 36-exposure film.

These figures are based on Minolta's standard test method using a fresh battery at 68°F (20°C). Actual battery performance will depend on how you use your camera.




FILM INFORMATION



Loading Film

1. Set the main switch to ON or  position.
2. Check the frame counter. When the frame counter shows "0" or if no number is displayed, it is safe to open the back cover.
 - The film window can also be used to check whether film is already loaded in the camera. Refer to page 17 if you want to rewind a partially exposed roll of film.

3. Open the back cover by pressing the button in the center of the back-cover release and sliding the release downward.
 - Always load film in subdued light or at least shaded from direct sunlight.
 - When you load film for the first time, remove and discard the protective plastic cover which is attached to the pressure plate.
4. Place film cartridge in film chamber as shown here.





5. Extend the tip of the film past the red mark. Make sure the holes in the lower edge of the film engage the teeth on the sprocket.

- If the film extends too far or does not lie flat, gently push the excess film back into the cartridge.

- Make sure the tip of the film is shaped correctly. Otherwise, the film may not wind properly.


- Do not touch any parts or areas shown in blue.



6. Close the back cover and make sure it snaps shut. The camera will automatically wind the film to the first frame. When the film is loaded correctly, the number "1" appears in the frame counter. If you are using DX-coded film, the film speed is set automatically and displayed for 5 seconds. You are now ready to start taking pictures.

- If the film is not loaded correctly, the frame number and film-transport signals "0" will blink, the camera will beep for one second and the shutter cannot be released. Repeat steps 3 through 6.

Automatic Setting Of The Film Speed




If you are using a DX-coded film, the camera sets the film speed automatically. The film-speed setting is displayed in the data panel for five seconds after the film is loaded.


- All DX-coded films have "DX" printed on their film cartridges and film boxes.


Manual Setting Of The Film Speed


If you are not using DX-coded film (i.e., "DX" is not printed on the cartridge and film box), you must manually set the correct ISO film speed. When desired, you can override the DX-coded film speed and reset the film speed to a higher or lower value. The film speed can be set from ISO 25 to ISO 6400. To set the film speed manually, see next page.




To set the film speed manually:

1. Open the card door on the right side of the camera.
2. Press the film-speed () button. Lift your finger from the button. The current film-speed setting will be displayed in the data panel next to the "ISO" symbol.



3. Move the up/down control to the left to set a lower film speed and to the right to set a higher film speed.
 - Each time you move the up/down control, the film speed changes by 1/3 of a stop. The speed changes rapidly if you hold the up/down control in either position.
4. After the desired film speed is set, press the shutter-release button lightly to return to the normal operating mode.
 - The normal display returns after 5 seconds.
 - You can check the film speed at any time by pressing the film-speed () button.

Automatic Film Rewind




After the last frame is exposed, the camera automatically starts rewinding the film. When a fresh battery is loaded in the camera, it normally takes about ten seconds to rewind a 36-exposure film and about eight seconds for a 24-exposure film.

When the film is completely rewound, the rewind motor switches off automatically. The film-cartridge symbol blinks in the data panel to indicate that you can remove the film.


- The film leader will be wound all the way into the cartridge. If you want the film leader to be left out after the film is rewound, you can use the Customized Function Card to change this function. See page 61 for more details about this and other Creative Expansion Cards.
- If you accidentally open the camera's back cover before the film is rewound, close the back cover immediately and press the rewind button to finish rewinding the film. Light falling on the film will ruin many of the pictures; however, your quick action may save a few pictures.
- If it's necessary to change the battery before rewind is completed, press the rewind button to restart.

Manual Start of Film Rewind

You can also rewind and remove a roll of film before the last exposure is taken. To start film rewinding, simply open the card door on the right side of the camera, and press the rewind () button.

TAKING PICTURES

TAKING PICTURES




Holding The Camera


This section explains the basic steps for using program exposure mode, autofocus, and single-frame film advance. Detailed information about each of the camera's functions begins on page 22.

To obtain sharp, blur-free photos, hold the camera as still as possible and steady it against your face or body. Press the shutter-release button gently with a slow, steady squeeze — never a quick jab.


Two recommended ways of holding the camera are shown here. If you grasp the camera firmly with your right hand on its handgrip, you can shift the camera back and forth for horizontal and vertical pictures without removing your hands from the controls. **When using autofocus, make sure you do not touch the lens' focusing ring.**

Fully Automatic Operation



1. Slide the main switch to  position, then press the program-reset (P) button to set the camera for fully automatic operation.


● Whenever the program-reset button is pressed, the camera is set to program exposure mode, autofocus, single-frame film advance, ± 0.0 exposure adjustment, and wide focus area.



2. Hold the camera firmly in your right hand and support the lens with your left hand.

● Do not touch the lens' focusing ring, as this prevents the lens from focusing properly.

3. While looking through the eyepiece, center the focus frame on your subject and press the shutter-release button partway down. The camera will focus automatically, and the exposure settings will be displayed in the viewfinder and data panel.




- A green focus signal in the viewfinder glows when the subject is in focus.
- If a red focus signal blinks, you should focus the lens manually or use focus hold (see page 27).
- If the camera beeps continuously, the shutter speed is too slow to ensure sharp pictures. Attach a flash unit or mount the camera on a tripod.



4. To take a picture, gently press the shutter-release button all the way down. Use a smooth, steady squeeze — never a quick jab which might shake the camera and cause a blurred picture.
- After the exposure is made, the film is automatically advanced to the next frame and the frame number increases by one.

MAKING THE MOST OF YOUR CAMERA

| | |
|------------------------|----|
| Main Switch | 23 |
| Focusing | 24 |
| Film-advance Modes | 33 |
| Exposure Control | |
| Program mode | 34 |
| Aperture-priority mode | 38 |
| Shutter-priority mode | 41 |
| Manual mode | 44 |



MAIN SWITCH




The main switch has three positions: LOCK, ON, and . At ON and  positions, you can take pictures and all camera functions will operate. At LOCK position, all camera functions are switched off.


When the camera is not in use, we recommend setting the main switch to LOCK to prevent taking accidental exposures and ensure optimum battery life.

Audible Signals

With the main switch at ON or  position, the camera beeps for one second to warn that the film has been loaded incorrectly. The camera will also beep if battery power becomes too low for continued operation. This signal will occur when the main switch is moved from LOCK to ON or  position.

With the main switch is at  position, the camera beeps when the subject comes into focus, when the shutter speed is too slow for taking hand-held pictures in program (P) or aperture-priority (A) mode, and when using the self-timer.

FOCUSING SYSTEM



Focus-area Selection



The Maxxum 7000i camera has three auto-focus sensors, a horizontal sensor in the center of the frame and vertical sensors on each side of the center sensor. When the camera is set to "wide" focus area, all three sensors are used to determine correct focus. When the "center" focus area is selected, only the horizontal sensor is used.

Wide Focus Area

The wide focus area is set automatically by the camera when you load a battery or when you press the program reset (P) button. This is the camera's normal setting, and it is ideal for most situations, especially when taking pictures of fast-moving subjects. Even if the main subject is not in the exact center of the frame, the camera will focus correctly.

Center Focus Area

If the camera is set to wide focus area, it may be difficult to focus on one person standing in a crowd, since more than one subject will fill the focus area. By selecting the center focus area, you can limit the focus area to the small area marked in the center of the viewfinder. The center focus area is also useful when you are taking close-up photographs.



To select the focus area:

1. Press the function-selector (←) key to move the function pointer under the focus area indicator.
2. Hold down the function-adjustment (FUNC) button and move the up/down control in either direction to select center (↕) or wide (↔) focus area.

- Both focus-area settings can be used with autofocus and manual focus.
- An indication in the viewfinder appears when center focus area is selected.
- To quickly reset the wide focus area, you can press the program reset (P) button. This will also set the camera to program mode, autofocus, single-frame advance, and +/-0.0 exposure adjustment.